

To be done

Bolt Radio MT to Floor

" Fuse Block to Floor

Bolt Speaker for Jeff's Radio

down

Hook up Crd Wire for Twister
Switch to Turn Radio's on
& off (Via Selwood.)

PL 259 installed on cable
for VHF

Antenna for IC 706

Green & Orange wire needs to
be better connected to power
cable for Jeff's Radio

Done

All Radios Wired to
Fuse Block

All Power Wires have been
re-routed & labeled

~~All Radios~~

New Circuit From Radio
Battery to Fuse Block

VHF Antenna ~~connected~~ to 706

VHF Ant Connected

VHF/UMF Connected to Kenwood
Ant Connected to Jeff's Radio